

Reader Extension cable wiring

IMPORTANT NOTICE

Using Immotec's Reader Extension cable

Please connect one end of the cable directly onto the controller (the cable comes with the white adapter to connect directly onto the controller) and the other end of the cable connect as follows:

Black wire from the reader to **Black and white dots** cable on the new wire

Yellow wire from the reader to **White** cable on the new wire

Green wire from the reader to **Black and red dots** cable on the new wire

Red wire from the reader to **red** wire

It is VERY important to connect **Ground** cable to the **Yellow and white cables** (all 3 wires together)

